

Cutting Instructions

Bass Drum or Tom Heads

1. Remove drum head. Place the drum head, preferably face down, on card board or posterboard, on a hard surface.
2. Select a location on the drum head, where the TOM PORT or Bass Drum O is to be placed. Leave at least a 1" to 2" distance from the edge of the drum rim. We recommend placement, away from the center of the head, for as much front-head tone, as possible.
3. Select one of the 9 marked slots, for the desired hole size and insert the center point into the cutting tool. You can see the hole size, at the bottom of each slot, in inches.
4. Do a practice spin to determine where the center of the hole will be.
5. Press the center point into the head then press firmly over the cutting wheel and center point while spinning the tool.