



**IMPORTANT!** Stick tip should be fully behind cloth disc mallet head. If Topper head can be easily bent, it is NOT adequately seated.

